



**OPERATION AND MAINTENANCE
INSTRUCTIONS**

FOR

**6636 SERIES PACKAGE
AIR CONDITIONER**

TABLE OF CONTENTS

| | | |
|------|---------------------------|---|
| I. | Specifications | 2 |
| II. | General Information | 2 |
| III. | Maintenance | 3 |
| IV. | Warranty | 3 |

I. SPECIFICATIONS

6636D771

MODEL NO. SERIAL NO.
FOR OUTDOOR USE ^ TOP ^
ELEC. RATINGS: 115 VAC 60 Hz 1 PHASE

| | | |
|------------|------------------------------|------------|
| CIRCUIT #1 | COMPRESSOR | CIRCUIT #2 |
| 8.5 RLA | 1450-234 | RLA 8.5 |
| 49.0 LRA | MOTOR THERMALLY PROTECTED | LRA 49.0 |
| 8.7 BCSC | | BCSC 8.7 |

| | | | |
|---------|------------------------|----------|---------|
| 3.4 FLA | I.D. BLOWER MOTOR DATA | H.P. 1/3 | FLA N/A |
| 2.8 FLA | D.D. BLOWER MOTOR DATA | H.P. 1/3 | FLA 3.7 |

| | | |
|---|--|-------------|
| 17.0 AMP | MIN. CIRCUIT AMPERAGE | AMP 14.6 |
| 20 AMP | MAXIMUM OVERCURRENT PROTECTIVE DEVICE | AMP 20 |
| 17.50 OZS. | R-22 CHARGE WEIGHT | OZS. 17.50 |
| MINIMUM EXTERNAL STATIC PRESSURE .43 IN. W.C. | | |
| *12 0'-25' | MINIMUM SUPPLY CONDUCTOR GAUGE (COPPER) | 0'-25' *12 |
| *10 25'-40' | | 25'-40' *10 |
| *8 40'-63' | UTILISER DES FILS D'ALIMENTATION EN CUIVRE | 40'-63' *8 |

WARNING: RISK OF ELECTRIC SHOCK!!! CAN CAUSE INJURY OR DEATH. DISCONNECT ALL REMOTE ELECTRIC POWER BEFORE SERVICING.

AVERTISSEMENT: RISQUE DE CHOCS ELECTRIQUES. PEUT CAUSER DES BLESSURES ET MEME ENTRAINDER LA MORT. COUPER LES SOURCES D'ALIMENTATION A DISTANCE AVANT LE DEPANNAGE.

DESIGN PRESSURES
HIGH SIDE 300 PSIG / LOW SIDE 150 PSIG

ROOM AIR
CONDITIONER
5K09

RV PRODUCTS
DIV. OF AIRXCEL INC., WICHITA, KS 6636A1B0

6636D871

MODEL NO. SERIAL NO.
FOR OUTDOOR USE ^ TOP ^
ELEC. RATINGS: 115 VAC 60 Hz 1 PHASE

| | | |
|------------|------------------------------|------------|
| CIRCUIT #1 | COMPRESSOR | CIRCUIT #2 |
| 7.6 RLA | 1450A211 | RLA 7.6 |
| 48.3 LRA | MOTOR THERMALLY PROTECTED | LRA 48.3 |
| 8.7 BCSC | | BCSC 8.7 |

| | | | |
|---------|------------------------|----------|---------|
| 3.4 FLA | I.D. BLOWER MOTOR DATA | H.P. 1/3 | FLA N/A |
| 2.8 FLA | D.D. BLOWER MOTOR DATA | H.P. 1/3 | FLA 3.7 |

| | | |
|---|--|-------------|
| 17.0 AMP | MIN. CIRCUIT AMPERAGE | AMP 14.6 |
| 20 AMP | MAXIMUM OVERCURRENT PROTECTIVE DEVICE | AMP 20 |
| 21.00 OZS. | R-22 CHARGE WEIGHT | OZS. 21.00 |
| MINIMUM EXTERNAL STATIC PRESSURE .43 IN. W.C. | | |
| *12 0'-25' | MINIMUM SUPPLY CONDUCTOR GAUGE (COPPER) | 0'-25' *12 |
| *10 25'-40' | | 25'-40' *10 |
| *8 40'-63' | UTILISER DES FILS D'ALIMENTATION EN CUIVRE | 40'-63' *8 |

WARNING: RISK OF ELECTRIC SHOCK!!! CAN CAUSE INJURY OR DEATH. DISCONNECT ALL REMOTE ELECTRIC POWER BEFORE SERVICING.

AVERTISSEMENT: RISQUE DE CHOCS ELECTRIQUES. PEUT CAUSER DES BLESSURES ET MEME ENTRAINDER LA MORT. COUPER LES SOURCES D'ALIMENTATION A DISTANCE AVANT LE DEPANNAGE.

DESIGN PRESSURES
HIGH SIDE 300 PSIG / LOW SIDE 150 PSIG

ROOM AIR
CONDITIONER
5K09

RV PRODUCTS
DIV. OF AIRXCEL INC., WICHITA, KS 6636C1B2

II. GENERAL INFORMATION

This packaged air conditioner mounts below the floor of the vehicle. The innovative design makes it possible to maintain a smooth, free-flowing roof line for the vehicle. It also relocates all air conditioner noise and condensate drainage off the roof to below the floor of the vehicle.

This air conditioner contains a dual compressor refrigeration system. It combines the cooling capacity of two roof mounted air conditioners into one highly efficient and compact package.

Each compressor is connected to a separate refrigeration circuit. The system can be operated with a single compressor when the cooling requirement is low, or with two compressors when maximum cooling performance is required.

Air Conditioner:

This air conditioner operates a two-stage cooling system. The first compressor and refrigeration circuit is referred to as "1st Stage Cooling". The second compressor and refrigeration

circuit is referred to as “2nd Stage Cooling”. First and second stage cooling will operate as indicated below.

1st stage cooling (the first compressor and refrigeration circuit), will operate when:

- 1) The thermostat is demanding cooling,
- 2) The vehicle is being powered by either shore line or the on-board generator.

2nd stage cooling (the second compressor and refrigeration circuit), will operate when:

- 1) The thermostat senses room temperature is 2 degrees higher than setpoint.

Thermostat operation is described in the operation instructions found with the wall thermostat.

III. MAINTENANCE

One of the biggest advantages of owning an RV Products air conditioner is that the maintenance needed to keep the unit in good care is minimal.

In fact, the only maintenance that must be taken care of on a regular basis is the cleaning or replacement of the air conditioner return air filters.

The manufacturer of your vehicle determines the number, size and location of the return air filters. Be sure to contact your dealer should you have any questions concerning the number of filters used and their location.

The return air filters of this system will accumulate dust and dirt more quickly than ceiling mounted air conditioning systems. We recommend that the filters be checked on a weekly basis.

If the filters are not cleaned or replaced at regular intervals, they may become partially clogged with lint and dirt. A clogged filter will produce a loss of air volume and may eventually cause equipment damage.

Do not operate the air conditioner without return air filters. Operating the system without filters allows the lint and dirt that is normally stopped by the filter to accumulate on the cooling coil of the air conditioner. This also will lead to a loss of air volume, possible equipment damage and an expensive cleaning process.

Periodically (once or twice a season), inspect the outdoor coil and brush off any accumulated residue with a soft bristled brush.

IV. WARRANTY

Let’s face it. Sometimes even the best products may need service. To obtain warranty service on your RV Products air conditioner, please contact your selling dealer, or you may access our web site on the Internet at www.rvcomfort.com for answers to the most frequently asked questions and service center locations.

RV Products support help may be accessed by E-mail at RVPSupport@Airxcel.com

All written correspondence should be directed to:

**RV Products
A Division of Airxcel, Inc.
P.O. Box 4020
Wichita, KS 67204**

IMPORTANT

1. Carefully read your limited two year product warranty which is packed with the product.
2. An optional three year extended parts only contract is available at an additional cost of \$89.95. To obtain this optional three year parts contract, fill out the application card stapled to the front of this envelope. Please mail the card and a check or money order to the address above. Applications must be made **within ninety (90) days** of the original purchase.
3. Inquiries about your RV Products air conditioner must include the model and serial numbers and the date of purchase. The model and serial numbers can be found on the air conditioner rating plate.



RV Products
A Division of Airxcel, Inc.
P.O. Box 4020
Wichita, KS 67204